

内蔵音楽データ一覧・Built-in Music Data Lists・Listas de datos de música incorporados・Listen der vorinstallierten Musikdaten・Listes des données de musique intégrées・Ingebouwde muziekgegevenslijsten・Liste dei dati musicali incorporati・Listor över inbyggda musikdata・Listas dos dados de música incorporados・内置音乐数据列表・内置音樂資料列表・Списки встроенных музыкальных данных・Dahili Müzik Veri Listeleri

音色リスト	Tone List	Lista de tonos	Klangfarbenliste	Liste des sonorités	Toonlijst	Lista dei timbri
① カテゴリー名	Category Name	Nombre de la categoría	Kategoriename	Nom de catégorie	Categoriennaam	Nome di categoria
② 番号	Number	Número	Nummer	Numéro	Nummer	Numero
③ 音色名	Tone Name	Nombre del tono	Klangfarbenname	Nom de sonorité	Toonnaam	Nome di timbro
④ プログラムチェンジ	Program Change	Cambio de programa	Programmwechsel	Changement de programme	Programmaverandering	Cambio di programma
⑤ バンクセレクトMSB	Bank Select MSB	MSB de selección de banco	Bankwahl MSB	MSB sélection de banque	Bankselectie MSB	MSB di selezione banco
⑥ DSPトーン	DSP Tone	Tono DSP	DSP-Klangfarbe	Sonorité DSP	DSP-toon	Timbro DSP

Tonlista	Lista dos sons	音色列表	音色列表	Перечень тембров	Ton Listesi
① Kategorinamn	Nome da categoria	类别名	類別名	Название категории	Kategori Ismi
② Nummer	Número	编号	編號	Номер	Numara
③ Tonnamn	Nome do som	音色名	音色名	Название тембра	Ton Ismi
④ Programändring	Mudança de programa	程序变化	程式變化	Смена программы	Program Değişikligi
⑤ Bankval MSB	MSB de seleção de banco	库选择MSB	庫選擇MSB	Выбор банка, старший разряд	Bank Seçimi MSB
⑥ DSP-ton	Som DSP	DSP 音色	DSP 音色	ЦОС-тембр	DSP Tonu

GRAND PIANO

001	Privia GRAND HG	0	3	
002	Privia GRAND HG BRIGHT	1	1	
003	Privia GRAND HG MELLOW	0	2	
004	Privia GRAND NY	0	17	
005	Privia GRAND NY BRIGHT	0	18	
006	Privia GRAND NY MELLOW	0	19	
007	Privia GRAND BN	0	20	
008	Privia GRAND BN BRIGHT	0	21	
009	Privia GRAND BN MELLOW	0	22	

BEST-HIT PIANOS

010	IMAGE PIANO	1	20	DSP
011	CLOCK PIANO	1	21	DSP
012	LET PIANO	1	22	DSP
013	YOUR PIANO	1	23	DSP
014	HUMAN PIANO	1	24	DSP
015	THOUSAND PIANO	1	25	DSP
016	PIANO LIKE YOU	1	26	DSP
017	RHAPSODIC PIANO	1	27	DSP
018	LADY PIANO	1	28	DSP
019	V.INSANE PIANO	1	29	DSP
020	HARD TO PIANO	1	30	DSP

VARIOUS PIANOS

021	STAGE PIANO	0	1	DSP
022	BALLAD PIANO	0	40	DSP
023	GRACEFUL PIANO	0	41	DSP
024	CRISP PIANO	0	42	DSP
025	FINE UPRIGHT	0	43	DSP
026	STANDARD UPRIGHT	0	44	DSP
027	RAGTIME PIANO	3	20	DSP
028	CONCERT HALL GRAND	0	45	DSP
029	COOL GRAND	0	46	DSP
030	DANCE PIANO	1	3	DSP
031	LA PIANO	1	4	
032	TACK PIANO	0	33	DSP
033	HONKY-TONK 1	3	32	
034	HONKY-TONK 2	3	34	DSP
035	OCTAVE PIANO 1	3	33	DSP
036	OCTAVE PIANO 2	3	35	DSP
037	STRINGS PIANO	0	34	
038	PIANO PAD	0	35	
039	NEW AGE PIANO	0	38	DSP

CLASSIC E.PIANOS 1

040	TAXI EP	4	54	DSP
041	FLYING BUTTER EP	4	39	DSP
042	STILL CRAZY EP	4	52	DSP
043	NEO SOUL EP	4	43	DSP
044	JUST THE WAY EP	4	31	DSP
045	NOT IN LOVE EP	4	51	DSP
046	STORM RIDER EP	4	50	DSP
047	NOT LIKE EP	4	42	DSP
048	JUST LIKE THAT EP	4	30	DSP
049	SPACE BOY EP	4	29	DSP
050	WAY OF THE WORLD EP	4	53	DSP
051	HONEY EP	4	40	DSP
052	LOVIN' U EP	4	34	DSP
053	DIAMOND EP	4	38	DSP
054	MAD SUMMER EP	4	33	DSP
055	MY BEST EP	4	45	DSP
056	INDESTRUCTIBLE EP	4	46	DSP
057	HATHA EP	4	55	DSP
058	DARK SIDE EP	4	56	DSP
059	WHERE IT IS EP	4	57	DSP
060	SWEET TABOO EP	5	22	DSP
061	GREATEST LOVE EP	5	23	DSP
062	EU EP	5	25	DSP
063	FOOTPRINTS EP	5	21	DSP
064	HARD HABIT EP	5	24	DSP
065	WHAT A FOOL EGP	2	35	DSP
066	THE LINE EGP	2	36	DSP
067	MAGICAL EP	4	41	DSP
068	NO QTR EP	4	44	DSP
069	DODODODO EP	4	49	DSP

CLASSIC E.PIANOS 2

070	STAGE EP	4	24	DSP
071	AMP EP	4	26	DSP
072	PHASER EP	4	15	DSP
073	CRUNCH EP	4	23	DSP
074	DYNO EP	4	17	DSP
075	60'S EP	4	6	DSP
076	AMP 60'S EP	4	19	DSP
077	TREM 60'S EP	4	25	DSP
078	GXYSA EP	5	26	DSP
079	FMSA EP	5	27	DSP

CLAVI

080	SA DETUNE EP	5	28	DSP
081	LA FANTASIA	5	29	DSP
082	FM BELL HEAVEN	5	30	DSP
083	GALAXIA EP	5	16	DSP
084	90'S EP	4	21	DSP
085	DIGITAL EP	5	19	DSP
086	LUCENT EP	5	17	DSP
087	E.PIANOT	4	47	DSP
088	RM EP	4	48	DSP
089	ELEC.GRAND PIANO	2	32	DSP

HARPSICHORD

090	SUPER CLAVI	7	24	DSP
091	AMP CLAVI	7	34	DSP
092	WAH CLAVI	7	25	DSP
093	CLAVI	7	1	
094	HARPSICHORD 1	6	1	DSP
095	HARPSICHORD 2	6	32	
096	COUPLED HARPSICHORD	6	33	DSP
097	AMBIENT HARPSICHORD	6	35	DSP

VIBRAPHONE

098	VIBRAPHONE	11	24	DSP
099	VIBRAPHONE WIDE	11	3	
100	MARIMBA	12	32	
101	CELESTA	8	1	
102	GLOCKENSPIEL	9	1	
103	MUSIC BOX	10	32	

ORGAN 1

104	JS ORGAN	17	32	DSP
105	RTF FD ORGAN	16	32	DSP
106	ROCK OD ORGAN	18	32	DSP
107	TREMOLO ORGAN	16	5	DSP
108	DP ORGAN	16	4	DSP
109	JAZZ ORGAN	17	33	DSP
110	ELEC.ORGAN 1	16	1	DSP
111	ELEC.ORGAN 2	16	2	DSP
112	AMP ORGAN	16	24	DSP
113	ROCK ORGAN 1	18	24	DSP
114	HARD ROCK ORGAN	18	25	DSP
115	GOSPEL ORGAN	20	24	DSP
116	PERC.ORGAN 1	17	1	DSP
117	VELO.ORGAN	16	25	DSP

ORGAN 2

118	PERC.ORGAN 2	17	39	DSP
119	FULL DRAWBAR	16	3	DSP
120	ROCK ORGAN 2	18	2	DSP
121	F-ORGAN	16	26	DSP
122	V-ORGAN	16	27	DSP
123	CLICK ORGAN	17	37	DSP
124	ROTARY F-ORGAN	16	28	DSP
125	ROTARY V-ORGAN	16	29	DSP
126	CHAPEL ORGAN	19	34	DSP
127	PIPE ORGAN	19	2	DSP
128	THEATER ORGAN	19	1	
129	PUFF ORGAN	20	33	
130	REED ORGAN	20	25	DSP
131	ACCORDION FRENCH	21	32	DSP
132	ACCORDION ITALY	21	1	

STRING ENSEMBLE

133	STEREO STRINGS	48	32	DSP
134	MELLOW STRINGS	49	1	
135	BRIGHT STRINGS	49	2	
136	WARM STRINGS	48	5	
137	PIZZICATO STRINGS	45	32	
138	ORCHESTRA HIT	55	32	
139	STRING QUARTET	48	37	

SYNTH PAD

140	SYNTH-STRINGS 1	50	36	
141	SYNTH-STRINGS 2	50	37	
142	SYNTH-STRINGS 3	50	38	DSP
143	SYNTH-STRINGS 4	51	32	DSP
144	DIGITAL SYNTH-STR. 1	51	33	DSP
145	SUPER SAW PAD	90	6	
146	OLD TAPE PAD	88	5	DSP
147	FANTASIA	88	33	DSP
148	XENON PAD	88	32	DSP
149	70'S SYNTH-STR. 1	50	3	
150	70'S SYNTH-STR. 2	50	32	
151	80'S SYNTH-STR. 1	50	33	
152	80'S SYNTH-STR. 2	50	34	
153	DIGITAL SYNTH-STR. 2	50	4	DSP
154	FAST SYNTH-STRINGS	50	5	
155	SLOW SYNTH-STRINGS	50	35	
156	NEW AGE	88	2	

157	WARM PAD	89	1	
158	SPACE PAD	103	1	
159	SOUND TRACK	97	34	DSP

CHOIR

160	CHOIR AAHS	52	1	
161	SLOW CHOIR	52	32	
162	VOICE DOO	53	32	
163	VOICE UUH	53	33	
164	VOICE ENSEMBLE	54	2	
165	PROGRESSIVE VOICE	88	4	DSP
166	VOCODER	54	33	DSP
167	SYNTH CHOIR	54	34	DSP

GUITAR

168	NYLON GUITAR VELO.SLIDE	24	32	
169	STEEL GUITAR VELO.SLIDE	25	32	
170	DYNAMIC NYLON GUITAR	24	24	DSP
171	DYNAMIC STEEL GUITAR	25	24	DSP
172	NYLON STR.GUITAR	24	4	DSP
173	STEEL STR.GUITAR	25	3	DSP
174	12 STR GUITAR	25	5	
175	CRUNCH JAZZ GUITAR	26	3	DSP
176	CLEAN GUITAR 1	27	2	DSP
177	CLEAN LEAD GUITAR	27	24	DSP
178	CRY DIST GUITAR	30	24	DSP
179	CLEAN GUITAR 2	27	7	
180	MUTE GUITAR	28	1	
181	HUM BLUES GUITAR	29	5	DSP
182	VINTAGE OD GUITAR	29	37	DSP

BASS

183	ACOUSTIC BASS 1	32	2	
184	ACOUSTIC BASS 2	32	3	DSP
185	ACOUSTIC BASS 3 (For Music)	32	48	
186	ACOUSTIC BASS 4 (For Music)	32	49	DSP
187	ACOUSTIC BASS 5	32	1	
188	RIDE BASS	32	33	
189	FINGERED BASS 1	33	6	
190	FINGERED BASS 2	33	5	
191	FINGERED BASS VELO.SLAP	33	32	
192	PICKED BASS	34	1	
193	SLAP BASS	36	1	
194	FRETLESS BASS	35	32	
195	SYNTH-BASS 1	38	1	
196	SYNTH-BASS 2	39	2	
197	SYNTH-BASS 3	39	5	

SOLO STRINGS

198	SOLO VIOLIN	40	32	
199	VIOLIN	40	33	
200	VIOLA	41	32	
201	CELLO	42	32	
202	CONTRABASS	43	32	
203	HARP	46	32	

BRASS

204	STEREO BRASS	61	1	DSP
205	SOLO TRUMPET	56	1	
206	SYNTH-BRASS 1	62	32	DSP
207	BRASS SECTION 1	61	3	
208	BRASS SECTION 2	61	37	
209	SYMPHONIC BRASS	61	40	
210	SYNTH-BRASS 2	62	33	
211	SYNTH-BRASS STAB	62	39	DSP
212	WARM SYNTH-BRASS	62	38	DSP
213	TRUMPET 1	56	32	DSP
214	TRUMPET 2	56	36	DSP
215	MUTE TRUMPET	59	1	
216	TROMBONE	57	32	
217	FLUGELHORN	56	37	DSP
218	FRENCH HORN	60	32	
219	TUBA	58	32	

REED

220	SOLO TENOR SAX 1	66	5	DSP
221	SOLO ALTO SAX 1	65	42	DSP
222	SOLO SOPRANO SAX	64	37	DSP

223	SOLO TENOR SAX 2	66	1	
224	SOLO ALTO SAX 2	65	32	
225	BREATHY ALTO SAX	65	33	DSP
226	BREATHY S.SAX	64	34	
227	SOLO OBOE	68	32	
228	SOLO BASSOON	70	32	
229	ALTO SAX	65	1	DSP
230	BARITONE SAX	67	1	

ドラム音色リスト
① 音名
② ノートナンバー
③ DRUMS SET NAME
← STANDARD SET 1と同じ音です。

Drum Assignment List
① Key
② Note No.
③ DRUMS SET NAME
← indicates a key is assigned the same tones as it is for STANDARD SET 1.

Lista de asignación de batería
① Clave
② N° de nota
③ DRUMS SET NAME
← indica que se ha asignado a la tecla el mismo tono que STANDARD SET 1.

Schlagzeug-Sound-Liste
① Tonname
② Noten-Nr.
③ DRUMS SET NAME
← gibt an, dass einer Taste die gleichen Sounds zugewiesen sind wie für STANDARD SET 1.

Liste des sons de batterie
① Note
② No. de note
③ DRUMS SET NAME
← indique une touche associée aux mêmes sonorités que pour STANDARD SET 1.

Drumtoewijzingslijst
① Toets
② Nootnr.
③ DRUMS SET NAME
← geeft aan dat aan een klaviertoets dezelfde tonen toegewezen worden als voor STANDARD SET 1.

Lista di assegnazione batteria
① Tasto
② No. nota
③ DRUMS SET NAME
← indica che un tasto è assegnato agli stessi timbri come per STANDARD SET 1.

Trumtildelningslista
① Tangent
② Notnr
③ DRUMS SET NAME
← anger en tangent som är tilldelad samma toner som den är för STANDARD SET 1.

Lista das atribuições de bateria
① Tecla
② N° da nota
③ DRUMS SET NAME
← indica que uma tecla está atribuída com os mesmos sons de STANDARD SET 1.

鼓音分配表
① 音名
② 音符编号
③ DRUMS SET NAME
← 表示琴鍵上分配了与 STANDARD SET 1 相同的音色。

鼓音分配表
① 音名
② 音符編號
③ DRUMS SET NAME
← 表示鍵盤琴鍵分配了與 STANDARD SET 1 相同的音色。

Tabla de correspondencia de instrumentos de percusión
① Clave
② Número de nota
③ DRUMS SET NAME
← significa que una tecla se asigna a los mismos sonidos que para el conjunto STANDARD SET 1.

Таблица соответствия клавишам звуков ударных инструментов
① Клавиша
② Номер ноты
③ DRUMS SET NAME
← означает тот же звук, что и в стандартном наборе «STANDARD SET 1».

Davul Atama Listesi
① Tuş
② Nota No.
③ DRUMS SET NAME
← STANDARD SET 1'de olduğu gibi bir tuşun aynı tonlara atandığını belirtir.

			Tone Category: DRUM SET													
			③													
			393: STANDARD SET 1	394: STANDARD SET 2	395: DANCE SET 1	396: DANCE SET 2	397: DANCE SET 3	398: DRUM MACHINE SET	399: JAZZ SET	400: BRUSH SET						
C-1		0	Tabla Ge		Dance1 Kick 1		Dance1 Kick 2		Jazz Kick 18" Low Mute	Brush Snare Sweep Ten. 1						
D-1	C-1	1	Tabla Ka		Dance1 Kick 2		Dance1 Kick 3		Jazz Kick 18" Low	Brush Snare Sweep Ten. 2						
F-1	E-1	2	Tabla Te		Dance1 Kick 3				Jazz Kick 18" High Mute	Brush Snare Sweep Ten. 3						
E-1		3	Tabla Na		Dance1 Kick 4				Jazz Kick 18" High	Brush Snare Sweep Ten. 4						
F-1		4	Tabla Tun		Dance1 Kick 5					Brush Snare Sweep Ten. 5						
F-1	F-1	5	Dholak Ge		Dance1 Snare 1		Dance1 Snare 1		Jazz Snare Side Stick Snry/Off	Brush Snare Sweep Ten. 6						
G-1		6	Dholak Ke		Dance1 Snare 2		Dance1 Snare 2		Jazz Snare Shot Snry/Off	Brush Snare Sweep Ten. 7						
A-1	A-1	7	Dholak Ta 1		Dance1 Snare 3		Dance1 Snare 3		Jazz Snare Ghost Snry/Off	Brush Snare Sweep Short 1						
B-1		8	Dholak Ta 2		Dance1 Snare 4		Dance1 Snare 4		Jazz Snare Flam Snry/Off	Brush Snare Sweep Short 2						
A-1		9	Dholak Na		Dance1 Snare 5		Dance1 Snare 5		Jazz Snare Roll Cres.	Brush Snare Sweep Loop 1						
B-1	B-1	10	Dholak Ta 3		Dance1 Snare 6		Dance1 Snare 6		Jazz Snare Roll Loop	Brush Snare Sweep Loop 2						
C0		11	Dholak Ring		Dance1 Snare 7		Dance1 Snare 7		Jazz Snare Roll Cres.	Brush Snare Sweep Loop 2						
C0		12	Midangam Tha		Dance1 Snare 8		Dance1 Snare 8		Jazz Snare Ghost	Brush Snare Sweep Long 1						
D0	C0	13	Midangam Dhom		Dance1 Snare 9		Dance1 Snare 9		Jazz Snare Open Rim Shot	Brush Snare Sweep Long 2						
D0	E0	14	Midangam Dhi		Dance1 Tambourine		Dance1 Tambourine									
E0		15	Midangam Dhin		Hip-Hop Snare 4		Hip-Hop Snare 4			Brush Snare Sweep 1						
F0		16	Midangam Num		Hip-Hop Snare 3		Hip-Hop Snare 3			Brush Snare Sweep 2						
F0	F0	17			Techno Snare		Techno Snare			Brush Snare Sweep 3						
G0		18			Hip-Hop Rim Shot		Hip-Hop Rim Shot		Jazz Ride Cymbal Tip 2	Brush Snare Sweep 4						
A0	A0	19			Hip-Hop Snare 3 Rev.		Hip-Hop Snare 3 Rev.		Jazz Ride Cymbal Crash	Brush Snare Sweep 5						
A0	A0	20			DM2 Kick 1 Rev.		DM2 Kick 1 Rev.		Jazz Ride Cymbal Tip 3	Brush Snare Sweep Acc. 1						
A0	B0	21			Reverse Cymbal Gate		Reverse Cymbal Gate			Brush Snare Sweep Acc. 2						
B0		22			Hip-Hop Snare 4 Gate		Dance4 Snare Rev.			Brush Snare Sweep Acc. 3						
C0		23			Hip-Hop Snare 3 Gate		Dance4 Open Hi-Hat Rev.			Brush Snare Accent						
C0	C-1	24			Standard3 Snare 1 mp		Techno Snare Gate			Brush Snare Ghost						
D1		25			Standard3 Snare 1 mf		Hip-Hop Side Stick Gate									
D1		26			Standard3 Snare 2 mp		Hip-Hop Side Stick Gate									
E1	E-1	27	High Q		Hand Clap 2 Gate		Hand Clap 2 Gate		Jazz Pedal Open Hi-Hat	Jazz Pedal Open Hi-Hat						
E1		28	Slap													
F1		29	Scratch Push													
F1	F-1	30	Scratch Pull													
G1		31	Sticks													
A1	A-1	32	Square Click													
A1		33	Metronome Click													
B1	B-1	34	Metronome Bell													
C1		35	Standard1 Kick 2													
C2		36	Standard1 Kick 1													
D2	C-2	37	Standard1 Side Stick													
E2		38	Standard1 Snare 1													
F2	E-2	39	Hand Clap 1													
F2		40	Standard1 Snare 2													
F2	F-2	41	Standard1 Low Tom 2													
G2		42	Standard1 Closed Hi-Hat													
A2	A-2	43	Standard1 Low Tom 1													
A2		44	Standard1 Pedal Hi-Hat													
B2		45	Standard1 Mid Tom 2													
B2	B-2	46	Standard1 Open Hi-Hat													
B2		47	Standard1 Mid Tom 1													
C3		48	Standard1 High Tom 2													
C3	C-3	49	Standard1 Crash Cymbal 1													
D3		50	Standard1 High Tom 1													
D3	E-3	51	Standard1 Ride Cymbal 1													
E3		52	Standard1 Chinese Cymbal													
F3		53	Standard1 Ride Bell													
F3	F-3	54	Tambourine													
G3		55	Standard1 Splash Cymbal													
A3	A-3	56	Cowbell													
A3		57	Standard1 Crash Cymbal 2													
B3	B-3	58	VibraSlap													
B3		59	Standard1 Ride Cymbal 2													
C4		60	High Bongo													
C4	C-4	61	Low Bongo													
D4		62	Mute High Conga													
E4	E-4	63	Open High Conga													
F4		64	Open Low Conga													
F4	F-4	65	High Timbale													
G4		66	Low Timbale													
G4	A-4	67	High Agogo 1													
A4		68	Low Agogo 1													
A4		69	Cabasa 1													
B4	B-4	70	Maracas 1													
B4		71	High Whistle 1													
C5		72	Low Whistle 1													
C5	C-5	73	Short Guro													
D5		74	Long Guro													
E5	E-5	75	Claves 1													
E5		76	High Wood Block													
F5		77	Low Wood Block													
F5	F-5	78	Mute Cuica													
G5		79	Open Cuica													
A5	A-5	80	Mute Triangle 1													
B5		81	Open Triangle 1													
B5		82	Shaker													
B5		83	Jingle Bell 1													
C6		84	Bell Tree													
C6	C-6	85	Castanets													
D6		86	Mute Surdo													
E6	E-6	87	Open Surdo 1													
F6		88	Applause 1													
F6		89	Applause 2													
G6	F-6	90														
G6		91														
A6	A-6	92														
A6	B-6	93														
B6		94														
B6		95														
C7		96	Jingle Bell 2													
C7	C-7	97	Open Surdo 2													
D7		98	Cabasa 2													
D7	E-7	99	Maracas 2													
E7		100	Shaker 2													
F7		101	Mute Triangle 2													
G7	F-7	102	Open Triangle 2													
G7		103	High Agogo 2													
A7	A-7	104	Low Agogo 2													
A7		105														
B7	B-7	106														
B7		107														
C8	C-8	108														
C8		109	Tabla 1													
D8		110	Tabla 2													
E8	E-8	111	Tabla 3													
F8		112	Daf 1													
F8	F-8	113	Daf 2													
G8		114	Riq 1													
G8		115	Riq 2													