

User's Guide 5398

ENGLISH

Congratulations upon your selection of this CASIO watch.

Important!

- This manual provides a brief overview of your watch.

E-1

For a full Operation Guide and Q&A information about this product, go to the website below.
<http://world.casio.com/manual/wat/>



Configuring Home City, Time and Date Settings

- Configure Home City and summer time settings first. After that, configure time and date settings.

Rotary switch Operations




Important!

- With this watch, you do not need to pull out the rotary switch before rotating it.

1. In the Timekeeping Mode, hold down (A) until the flashing **Hold** indicator disappears from the display and the currently selected city code appears on the right side of the upper display.
 - This indicates the city code setting mode.

E-2

2. Press (C) to move the flashing in the sequence shown below to select a setting.



E-4

3. When the timekeeping setting you want to change is flashing, perform the operation described below.

Screen	To do this:	Do this:
TYO	Change the city code	Rotate the rotary switch.
OFF	Toggle between Daylight Saving Time (ON) and Standard Time (OFF)	
12H	Toggle between 12-hour (12H) and 24-hour (24H) timekeeping	Press (D).
36	Reset the seconds to 00	
10:08	Change the hour or minute	Rotate the rotary switch.
20 15	Change the year	
6 30	Change the month or day	


4. Press (A) to exit the setting mode.

E-5


Mode Selection and Operations

- Press (C) to change the mode.
- To return to the Timekeeping Mode from any other mode, hold down (C) for about two seconds.

Timekeeping Mode



Stopwatch Mode



World Time Mode



Countdown Timer Mode



Alarm Mode



E-6

E-7

Misaligned Hands

The analog hands may become misaligned as described below if the watch is exposed to strong magnetism, impact, or other abnormal conditions.

- Analog time and digital time are different from each other

If this happens, refer to "Adjusting Hand Positions" in the Operation Guide available at the CASIO website and adjust the hand alignment.

E-8

Specifications

Accuracy at normal temperature: ±15 seconds a month

Digital Timekeeping: Hour, minutes, seconds, p.m. (P), month, day, day of the week

Time format: 12-hour and 24-hour

Calendar system: Full Auto-calendar pre-programmed from the year 2000 to 2099

Other: Home City code (can be assigned one of 48 city codes);

Standard Time/Daylight Saving Time (summer time)

Analog Timekeeping: Hour, minutes (hand moves every 20 seconds)

Stopwatch:

Measuring unit: 1/100 second

Measuring capacity: 23:59'59.99"

Measuring modes: Elapsed time, split time, two finishes, Auto Start

World Time: 48 cities (31 time zones)

Other: Daylight Saving Time/Standard Time; Home City/World Time City switching

E-9

Alarms: 5 Daily alarms (four one-time alarms; one snooze alarm); Hourly time signal

Countdown Timer:

Measuring unit: 1 second
 Countdown range: 60 minutes
 Countdown start time setting range: 1 to 60 minutes (1-minute increments)
 Elapsed time: 60 minutes

Illumination: LED (light-emitting diode); Selectable illumination duration (approximately 1.5 seconds or 3 seconds); Auto Light Switch

Other: Button operation tone on/off; Moving the Hands to View the Digital Display

Power Supply: Two silver oxide batteries (Type: SR927W)

Approximate battery operating time: 3 years under the following conditions:

- 1 illumination operation (1.5 seconds) per day
- Alarm: 10 seconds/day

Frequent use of illumination runs down the battery.

Specifications are subject to change without notice.

E-10



City Code Table

L-1

City Code Table

City Code	City name	UTC Offset/ GMT Differential	City Code	City name	UTC Offset/ GMT Differential
PPG	PAGO PAGO	-11	RAI	PRAIA	-1
HNL	HONOLULU	-10	UTC		
ANC	ANCHORAGE	-9	LIS	LISBON	0
YVR	VANCOUVER	-8	LON	LONDON	
LAX	LOS ANGELES	-8	MAD	MADRID	
YEA	EDMONTON	-7	PAR	PARIS	
DEN	DENVER	-7	ROM	ROME	+1
MEX	MEXICO CITY	-6	BER	BERLIN	
CHI	CHICAGO	-6	STO	STOCKHOLM	
NYC	NEW YORK	-5	ATH	ATHENS	
SCL	SANTIAGO	-4	CAI	CAIRO	+2
YHZ	HALIFAX	-4	JRS	JERUSALEM	
YYT	ST. JOHN'S	-3.5	MOW	MOSCOW	+3
RIO	RIO DE JANEIRO	-3	JED	JEDDAH	+3
FEN	F. DE NORONHA	-2	THR	TEHRAN	+3.5

L-2

City Code	City name	UTC Offset/ GMT Differential
DXB	DUBAI	+4
KBL	KABUL	+4.5
KHI	KARACHI	+5
DEL	DELHI	+5.5
KTM	KATHMANDU	+5.75
DAC	DHAKA	+6
RCN	YANGON	+6.5
BKK	BANGKOK	+7
SIN	SINGAPORE	
HKG	HONG KONG	+8
BJS	BEIJING	
TPE	TAIPEI	
SEL	SEOUL	+9
TYO	TOKYO	
ADL	ADELAIDE	+9.5

City Code	City name	UTC Offset/ GMT Differential
GUM	GUAM	+10
SYD	SYDNEY	+10
NOU	NOUMEA	+11
WLG	WELLINGTON	+12

- This table shows the city codes of this watch (As of December 2013).
- The rules governing global times (UTC offset and GMT differential) and summer time are determined by each individual country.

L-3